

ABOUT US 公司簡介

我們自1989年起即為堆高機零件的專業製造商，產品行銷台灣及海外市場，包括歐洲、澳洲、美國、加拿大、俄羅斯、南非及東南亞各國。憑藉多年經驗與穩定品質，我們在全球市場建立了良好的商譽與可靠的市場基礎。我們是一家以品質為導向的企業，致力於高性能零組件的製造。

本公司產品涵蓋煞車系統、轉向系統、懸吊系統、傳動系統、底盤零件，以及多樣化的滾輪與軸承產品，如門架導輪、鏈條滾輪／滑輪、側向推力滾輪、單面封閉式軸承及針狀軸承等。此外，我們亦可依客戶規格，提供堆高機及農業機械用之客製化零件。

Since 1989, we have been a professional manufacturer of forklift parts, serving markets in Taiwan as well as Europe, Australia, the United States, Canada, Russia, South Africa, and Southeast Asia. With decades of experience and consistent quality, we have built a strong reputation and a reliable market presence worldwide. We are a quality-oriented company dedicated to the manufacturing of high-performance components.

Our product range includes brake systems, steering systems, suspension systems, power trains, chassis parts, and a wide selection of roller bearings, such as mast guide rollers, chain rollers / sheave rollers, side thrust rollers, single-side sealed bearings, and needle bearings. We also offer customized parts made to customer specifications, including components for forklift trucks and agricultural machinery.

目錄 *Contents*

BRAKE MASTER CYLINDER ASSEMBLY 剎車總邦	1
CLUTCH MASTER CYLINDER ASSEMBLY 離合器總邦	11
CLUTCH SLAVE CYLINDER ASSEMBLY 離合器分邦	13
BRAKE WHEEL CYLINDER ASSEMBLY 剎車分邦	15
BRAKE & CLUTCH MASTER CYLINDER KIT 修理包	23
BOOSTER AIR TANK 真空剎車補助器	24
UNIVERSAL JOINT 傳動軸	25
(DRIVE SHAFT / PROPELLER SHAFT)	
PUMP SEAT 邦浦座	29
CROSS / SPIDER 十字軸承	30
SHAFT ASSEMBLY 工字鐵、工字鐵總成	33
YOKE T型齒	35
PULLEY COUPLING 風扇皮帶盤、曲軸皮帶盤	37
FAN BELT ADJUSTING BAR 皮帶盤調整尺、發電機座	43
RING GEAR 飛輪齒	45
FLYWHEEL 飛輪盤	47
FLYWHEEL RING GEAR (MANUAL) 飛輪盤總成 - 手排	49
(FLYWHEEL PLATE ASSEMBLY)	
FLYWHEEL RING GEAR (AUTO) 飛輪盤總成 - 自排	51
(FLYWHEEL PLATE ASSEMBLY)	
CLUTCH DISC 離合器片	52
CLUTCH COVER 離合器壓板	53
FLYWHEEL HOUSING / DIFFERENTIAL FRONT COVER 飛輪殼、差速器前蓋	54
CLUTCH BEARING 離合器軸承	55
CLUTCH FORK 離合器撥叉	55
TRANSMISSION BEARING 變速箱軸承	56

目錄 *Contents*

TRANSMISSION SHAFT PIN BEARING 變速箱插肖	56
OIL PUMP (SPECIAL PURPOSE VEHICLE) 供油邦浦	57
RETAINER 離合器軸承座、變速箱後蓋	59
KNUCKLE (STEER STUB AXLE) 羊角	61
NUT FOR KNUCKLE 羊角螺母	75
KING PIN BUSH 羊角鐵套	77
HUB 哈夫 - 後輪軸殼	81
HUB CAP 哈夫蓋	85
FRONT HUB 前輪哈夫	86
BEARING HUB 哈夫軸承	87
OIL SEAL 油封	89
FRONT AXLE SHAFT 前輪車心、減速齒輪組	91
BRAKE DRUM 剎車鼓 - 制動輪鼓	97
BRAKE SHOE 剎車來令片	102
BRAKE LEVER 來令片修理包、剎車盤、踏板 - 鐵	105
SPRING 彈簧	109
CENTER ARM / BELL CRANK 三角盤	114
STUD BALL 三角盤球頭	117
FUEL PUMP 柴油邦浦	118
FUEL FILTER COVER UPPER 柴油芯上蓋	119
WHEEL RIM 鋼圈	120
SHAFT YOKE ASSEMBLY 方向機接頭	121
STEERING PUMP KIT 方向機邦浦修理包	123
STEERING WHEEL COVER 方向盤頭	124

目錄 *Contents*

INPUT PLATE 扭力中心蓋	125
HUB PUMP DRIVE 供油邦浦哈夫	126
INPUT PLATE 變速箱壓板	127
TORQUE CONVERTER 變矩器	131
ROUND CLAMP COG WHEEL 夾包齒輪	133
SHAFT BOLT / NUT / PIN 離合器芯軸	134
ENGINE MOUNTING & SUPPORT 引擎膠墊、變速箱膠墊	138
ACCELERATOR & CLUTCH PEDAL 踏板	142
BRACKET 引擎鐵腳、變速箱鐵腳	144
LIFT CHAIN / CONNECTING LINK 鏈條、鏈目	147
CHAIN EYE 鏈條接頭	148
BEARING SEAT 軸承座	149
BUSH 後擔墊木軸座	151
STRIP 桅桿墊片	152
CHAIN TENSIONER 鏈條調整螺絲	153
HOSE / SHEAVE PULLEY 油管附盤	156
SIDE ROLLER BEARING SEAT 邊滑輪固定座	157
PINION GEAR 差速斜齒輪組	158
WATER PUMP 水邦浦 - 日本製	161
WATER PUMP 水邦浦	162
POWER CYLINDER PIPE 動力缸油壓管	164
PUMP PIPE SUB-ASSEMBLY 進油管、迴油管	165
WATER INLET 水彎管接頭、鐵水管、水龜蓋上 / 下座	166
CONCAVE WATER LID 鐵水塞	168

目錄 *Contents*

CONNECTING ROD 連桿	169
CHAMBER 預燃室	170
KING PIN 大王肖	171
KING PIN KIT 大王肖修理包	180
WASHER / SHIM 大王肖 / 軸承 / 變速箱 墊片	184
CENTER PIN 中心肖	188
CENTER PIN KIT 中心肖修理包	191
HUB BOLT / NUT 輪胎螺絲	193
NUT 螺母	195
HUB BOLT / NUT 前輪螺絲	196
DRAIN PLUG (BOLT) , OIL PAN / DIFFERENTIAL 油底殼 (差速器) 螺絲	198
BOLT STOPPER 大王肖止肖	199
SCREW ADJUSTING 剎車調整器	200
TIE ROD LINK 連結器	201
PIN 連結器 (油壓缸) 插肖	205
PIN FOR LIFT BRACKET 傾斜缸插肖	211
COLLAR 鋼套、滾輪邊側蓋	213
PIN FOR SIDE SHIFT CYLINDER 側移缸插肖	217
BUSHING 桅桿前半圓墊木	218
BUSHING 後擔墊木	221
BUSHING 膠套	223
CAP MAST SUPPORT 桅桿墊木座	225
ROD ASS'Y SHIFT 排檔拉桿、排檔座	226
CONNECTING ROD 拉線 (排檔) 球頭	229

目錄 *Contents*

TIE ROD END 橫拉桿接桿	230
TIE ROD END 方向機拉桿	233
TIE ROD END 和尚頭拉桿	234
POWER STEERING CYLINDER ASS'Y 動力缸總成	237
U-BOLT / SUPPORT U型鎖	238
POWER ROD KIT 動力缸球頭修理包	239
HYDRAULIC PUMP REPAIR KIT 油壓邦浦修理包	239
POWER ROD 動力缸芯	240
TILT ROD 傾斜缸芯 - 伸手芯	242
TILT ROD KIT 傾斜缸芯 - 伸手芯修理包	251
LIFT CYLINDER REPAIR KIT 升降油壓缸 - 修理包	252
ROD END 伸手芯固定環	254
ROD SUB - ASSEMBLY 全油壓缸芯	255
ROD SUB - ASSEMBLY KIT 全油壓缸芯修理包	258
REAR STEERING CYLINDER ASS'Y 全油壓缸總成	259
SIDE SHIFTER 側儀油壓缸	260
TILT CYLINDER ASS'Y 伸手芯總成	261
TILT CYLINDER CAP 伸手芯帽頭	262
EYE BALL 魚眼軸承	263
ENGINE FAN 風扇	264
CABLE 來令線	267
CLUTCH CABLE 離合器線 (排檔線)	268
ACCEL CABLE 加油線	269

目錄 *Contents*

BRAKE CABLE 剎車線	272
ENGINE COVER WIRE CABLE 引擎蓋拉線	279
CABLE 熄火拉線	279
CABLE 方向機拉線	279
SWITCH 溫度 / 倒車 / 剎車 開關	280
PLUNGER 柱塞-方向盤撞針	281
TANK UNIT 浮桶、油箱蓋	281
BACK BUZZER 倒車喇叭-蜂鳴器	281
BULB 燈泡	282
LIGHT BRACKET 燈架	282
GRIP 上車把手	283
HINGE 後鈕	283
CHAIR 椅子	283
HOOD DAMPER 引擎蓋頂桿	284
GLOW PLUG 預熱塞	285
KNOB ASS'Y 牙拴	287
TRANSMISSION DISC 摩擦墊片	289
TRANSMISSION GEAR & DIFFERENTIAL GEAR 齒輪	293
ROLLER BEARING 軸承、針狀軸承、平面軸承	304
SIDE THRUST ROLLER 側滾輪軸承	337
CONNECTING SEAT BEARING 連座軸承	344
HYDRAULIC PUMP (KAYABA) 油壓邦浦	347